



Care instructions veneered furniture

Wood is a fantastic material, we have it all around us in the nature!

We make the vast majority of our furniture in wood or veneer. What one has to think about is that like everyone natural materials, the wood also changes its appearance as time goes by.

Factors such as light and use affect how quickly the wood matures and changes shade. If you leave something lying on the table top longer than a week, lighter marks can easily occur. Some woods, for example oak, birch, beech, ash and walnut, matures faster than others.

Temperature and humidity also affect how the wood behaves; if it swells, shrinks etc. Therefore, you should regularly adjust the hinges, screws and fittings. The different woods have all their charms, and their special properties. But there are some common denominator for all types of wood.

Whatever wood furniture you choose, consider the following:

- Moisture is the wood's worst enemy. Therefore wet soils, even ordinary water, must be dried up so quickly as possible. You can easily clean your wooden furniture with a damp cloth and soap solution.

**Wipe with a dry cloth. If not, cracks and / or changes can occur in the wood that cannot be repaired!
Furniture polish must not be used!**

Heat can damage the wood. Remember to always protect the surface against hot objects such as pans, hot coffee or tea cups and warm candles. If not, marks can arise that cannot be repair!

Never place a wooden furniture near an element or other heat source. The wood can then dry with cracks as a result. Furniture for indoor use should never be used outdoors because the temperature changes can damage the wood.

A wooden furniture that is properly managed gives life and joy to the office or home for many years to come!

Keep the above mentioned in mind so you will be able to enjoy Your Horred's furniture for many years.